


FAQ

How to Make Automatic Prostate Measurement

[FAQ – ProstateAssist™]

- Question
The **Assist** button is active when scanning the prostate, but measurements still need to be made manually. Why is that?



- Answer

■ Path: Setup > Assist > Urology

Make sure **ProstateAssist** is set to **On**.

- ▶ If **Off** is selected, **Assist** functions will not work automatically, even if the button is active.

