

FAQ

How to Use Reverse Depth Control

[FAQ – Reverse Depth Control]


- Question
I want to reverse the method of adjusting the depth.
How can I do that?

- Answer

■ Path: Setup > Imaging > Operation

Check or uncheck **Reverse Depth Control** option.

- ▶ This option allows you to change the method of adjusting the depth based on your preference or habits from using other systems.



- By default, moving the depth switch upward makes the image shallower (decreases the scanning depth).
- When **Reverse Depth Control** is enabled, moving the depth switch upward increases the scanning depth, making the image deeper.