

## FAQ

# How to Set the Deletion Order When Using the Clear Key

## [FAQ – Deletion Order]

- Question  
When I press the **Clear** key, in what order are items deleted? Can I change that order?
- Answer
  - Path: Setup > System > General
  - 1. Go to **Deleting Order**.
  - 2. Use the up/down arrows(▲/▼) to rearrange the item order.
  - 3. The new order determines which item is deleted first when pressing the **Clear** key.

