

FAQ

How to Move the Color Box and PW Line Counterclockwise to Fine Tune Steer

[FAQ – Reverse of Fine Tune Steer]


- Question
How do I have the **Color ROI** and **PW Line** move **counterclockwise** to the direction of **Fine Tune Steer**?

- Answer

■ Path: Setup > Imaging > Operation

Select **Steer Reverse Rotation Controls**.

- ▶ By default (when unchecked), turning the knob left (counterclockwise) moves **Color ROI** and **PW Line** to the left.
- ▶ When this setting is enabled, turning the knob left will move **Color ROI** and **PW Line** to the right.



- **Steer** is available only with linear transducers.
- Requires both **Color** and **PW modes** to be active.
- On the touchscreen, use the lower knob key labeled **Fine Tune Steer** to adjust the steering angle in 1° increments.