

FAQ

How to Reorder or Show/Hide Measurement Results

[FAQ – Measurement Results]


- Question
Can I change the order of measurement results or show/hide the result items?

- Answer

■ Path: Setup > Measurement > Menu > Measurement

1. Select the relevant measurement item.
2. Locate the corresponding result item in **Display** at the bottom-right of the monitor screen and check or uncheck it.

▮▮▮▮ Measurement results ≡ Report page



Use Caliper

- You can select the tool type for measurement and adjust its order.