

FAQ

How to Keep Current Scan Settings When Changing Preset

[FAQ – Geometry Change]

- Question
Can I keep my current depth and zoom settings when switching **Preset** during a scan?

- Answer

■ Path: Setup > Imaging > Operation

1. Go to **Geometry Change** settings.
2. Turn **On** the option **Keep Scan Geometry when Preset is Activated**.
3. Check the boxes for the specific items you want to maintain, such as Depth, Image Size, or Zoom.

